




Operating Volume - Volume of water calculated based on the water line falling 5" below the coping.

ALL MEASUREMENTS AND QUANTITIES ARE BASED ON AVERAGES